

SPI Panel Cleaning Instructions with Guilford Fabrics

All panel finishes are subject to soiling. Regular, light maintenance will prevent staining from soil build-up. Note: extra care is typically required for panels installed adjacent to HVAC outlets.

SPI recommends pre-testing any cleaning materials or method on a small inconspicuous area before proceeding to clean the panel fabric surface. Caution: Aggressive fabric cleaning methods may damage fabric or underlying panel materials.

- Gentle vacuuming or light brushing is recommended to prevent dust and soil buildup.
- Lightly blot fresh spills immediately with a clean, absorbent cloth. Work from the outer edge of the stained area, moving inward. In order to effectively draw out the stain, renew the cleaning cloth frequently. Dry the fabric as quickly as practical.
- Clean fabric only with water based cleaning agents, foam or pure, water free solvents